

SNP131 MAG License Plate Recognition

AG



MAG



Device Interface Description



No.	Function	Label	Description
1	Power	DV12V; GND	Standard 12V/2A
2	Network Interface	RJ45/LAN	Support 10/100Mbps Ethernet transmission
3	Serial Port (RS485)	A1/B1	Connect to LED Display
4	Audio	AIN\AOUT\GND	Audio input /output.
5	IO Output (Alarm Out)	OUT1/OUT2	Can be used for barrier gate opening
6	IO Input (Alarm In)	IN1/2/3/4 /GND	Used for external signal trigger
7	Light Interface	LED+/LED-	Used to power & control LED Camera
8	USB Interface	USB	USB Type A interface
9	SD Card Slot	TF-CARD	SD card slot, maximum 128GB
10	Reset	RESET	Press for 5 to 10 seconds for a long time, and the equipment will fully restore to factory configuration
11	Indicator Light	SYS (green)	Flashing means the system is currently working properly, whereas continuous on or off means starting or abnormal

© 2025 QG V2.1 SNP131 MAG LPR





Equipment Installation

LPR Camera Installation



Fig. 1: Installation diagram of LPR Camera

I	nstallation Requirements	Installation Height			
 Install in front of the barrier gate About 3-6 meters from the virtual coil, L1. About 3-4 meters from loop detector, L2 		 For frequent small car entry, the recommended height of camera is about 1.4m above the ground For frequent large truck entry, the recommended height of camera is about 1.6m above the ground The angle of camera installed is recommended to be between 15° and 40° and as far as possible. 			
No.	Effective identification distance, D (m)	Recommended installation height, H (m)	Corresponding angle (degree)		
1	3	1.4	~20°		
2	4	1.5	~20°		
3	5	1.6	~20°		

© 2025 QG V2.1 SNP131 MAG LPR



LED Fill Light Installation



Fig. 2: Installation diagram of LED Fill Light



Fig. 3: Example of wrong installation of LED (overexposure)

Installation Requirements:

- Distance, D: The recommended distance between the fill light and license plate is more than 2m and less than 6m
- Angle, C: The fill light should be angled so that it illuminates the license plate in the recognition area (around 15° 45°) and avoids overexposure
- Vertical Height, H: The fill light should be kept at a vertical distance of 0.5m 0.7m away from the LPR camera



Typical Installation Scenario of LPR Camera



Setting Up SNP131

1. The factory default IP configuration for SNP131 is **192.168.1.100 (username: admin, Password: admin)**

2. Before connecting to the camera, confirm whether the IP address of the current computer and the camera IP address are in the same network segment.

3. After powering up the LPR camera, open browser and input the IP address http://192.168.1.100 /



Fig. 4: Login Page



4. For first time setup using **Internet Explorer** browser, kindly install the plugin when the prompt pops up (not necessary for other browser types)

6	No controls installed? Cl	ick OK to start installing the	control. Please close
	to allow the control to run	lauon. Il il lo alleady installe. 1.	, please click Galicel
-		56	
		de	fine cancel

Fig. 5: Install plugin prompt (IE browser only)

5. Enter the default user name: admin, the default password admin, and click the login button to log in.

6. After logging in, the main interface is as shown below:



Fig. 6: Web Portal Main Page

7. In the real-time video display, the recognition area and virtual coil loop is marked by default.

8. To adjust both areas, use the red points on the vertex to adjust the shape and size of the recognition/identification area and the virtual coil loop area.

9. To add more red points for adjustment, double-click on the area to create a new red point.





Realtime display 📕 Best size of plate	
07/04/2023 Identify areas	05:30:23
Double click to add anchor points	
Virtual coil loop	
	me display Best size of plate
Remove loop Remove area Save rules	Lens

Fig. 7: Default Area Configuration of Recognition Area & Virtual Coil Loop

4. After completing the adjustment, click on "save rules" to save the configuration for both recognition area and virtual coil loop area.

5. To delete the drawn area, use the "remove loop" and "remove area" function to delete and redraw the areas

6. Use the Lens function to adjust the camera zoom according to site conditions.

Important Note:

Recognition/Identification Area: When the vehicle enters the identification area, it will start to identify and analyse the license plate;

Virtual Coil Loop: When the vehicle enters the virtual coil loop area (trigger area), the recognition result of the license plate will be sent.

© 2025 QG V2.1 SNP131 MAG LPR



Positioning of Virtual Coil Loop

1. When calibrating the recognition area and virtual coil loop area, you may separate the video screen into 3 segments. The Virtual Coil Loop should be positioned at the lower 3rd segment of the video height

2. Ensure that the left and right area of the Virtual Coil Loop is able to cover the car license plate.



Fig. 8: Positioning of Virtual Coil Loop

Recognition Area Full Coverage

1. When calibrating the recognition area, make sure to include the effective range of movement of the license plate on the screen



Fig. 9: Recognition Area Adjustment according to Site

2. When calibrating the recognition area, ensure more area is included for the vehicle to gain more video streams and more recognition frames for better accuracy





Event Capture

1. After completing the LPR calibrations, incoming vehicle car plates will be captured automatically and the identified license plate number will be displayed on the right side

Video snapshot	
12/30/2019 010858561 Black 534Ptxet 00000000000000000000000000000000000	
Car front recognition	Car plate picture
	Car plate recognition result
	Trigger

Fig. 10: Car Plate Identification Result

2. To manually trigger the car plate recognition, click on the "Trigger" button to manually capture a test image. The captured image will automatically display the close-up car image and the license plate, whereas the license plate number identified will be displayed on the right side.

3. Under the real-time display interface, there is a snapshot event history of all the car plates identified

Time	Plate	Width	Trigger	Car info	Car color
2019-12-30 10:49:19	D5MY1518	281Pixel	Virtual ground coil	Unknown	Unknown
2019-12-30 10:49:32	D5MV1518	291Pixel	Virtual ground coil	Unknown	Unknown
2019-12-30 10:49:32	D5MY1518	287Pixel	Virtual ground coil	Unknown	Unknown
2019-12-30 10:51:27	D1DB5858	483Pixel	Virtual ground coil	Unknown	Unknown
2019-12-30 10:51:54	D1DB5858	600Pixel	Virtual ground coil	Unknown	Unknown
2019-12-30 10:52:43	D1DB5858	534Pixel	Virtual ground coil	Unknown	Unknown

Fig. 11: Identified Car Plate Event Log



Device Settings

At the top of the interface, click on Options to enter the advanced setting menu as shown below:

Intelligent AN	PR Camera	leo Query data	Options	System
Recognition	Trigger mode			,
AV settings	Video trigger	Virtual coil loop	Stable recogr	nition
Basic network	External triager	Switch/electrical input	Switch/electri	ical input
White list	External uigger	1	2	
Advanced network		Switch/electrical input	Switch/electri	ical input
Peripherals		3	4	
Sync	Recognition parameter			
Screen voice	Image resolution	1920*1080	*	
Gateway configured	Image quality	70%	*	
	Result delay(MS)	3000		
	Car plate pixel limit (pixel)	80 - 600		
	Same plate trigger interval(s)	10		

Fig. 11: Advance Setting Interface

Recognition/ Identification Setting

1. Use the Trigger Mode to switch between different types of identification trigger.

2. Recognition parameters can be used to change image resolution, image quality, result delay, car plate pixel limit and same plate trigger intervals.

√ideo trigger	Virtual coil loop	Stable recognition
External trigger	Switch/electrical input 1	Switch/electrical input 2
	Switch/electrical input 3	Switch/electrical input 4
cognition parameter		
Image resolution	1920*1080	*
Image quality	70%	¥
Result delay(MS)	3000	
Car plate pixel limit (pixel)	80 - 600	

Fig. 12: Identification Setting Interface





	CK	GU	IDF
GUI	UN	00	

Basic Network Settings

Recognition	Basic setting	4G config	DDNS	UPNP	Network diagnosis
AV settings	D.				
Basic network	IP	1	192.168.3.2	29	
White list	Netmask	2	255.255.25	5.0	
Advanced network	Gateway	1	192.168.3.1	L)	
Peripherals	DNS server	1	14.114.114	1.114	
Sync	DNS server 2	8	3.8.8.8		
Screen voice	UTTO and				
Gateway configured	HTTP port	5	30		
	RTSP port	8	3557		
				Con	firm
				and the second s	

1. In the basic setting tab, you may configure the basic network settings as follows:

- IP address: To configure the network IP address.
- Subnet mask: To configure the subnet mask of the network.
- **Default gateway:** To configure the network default gateway. It should be in the same network segment as the IP address
- **DNS server:** To configure the DNS server of the network. After configuring the network parameters, click OK to take effect.
- **DNS server 2:** To configure the standby DNS server, and automatically switch to this DNS server when there is connection error in the default DNS server
- **HTTP port:** To configure the port number of HTTP protocol. The default is 80. Click OK to take effect.
- **RTSP port:** To configure the port number of RTSP video stream. The default is 8557. Click OK to take effect.





White List

1. In the white list configuration tab, you may configure white list as follows:

Recognition	Whiteist configuration Whitelist e	nquiry	
AV settings			
Basic network	Whitelist enable conditions		
White list	Offline auto start O Ena	ble O	Disable
Advanced network	Current camera offline 🕥		
Peripherals			
Sync	- Whitelist pattern match		
Screen voice	Exact match (Car plate fully re	cognition)	
Gateway configured	 Similar character matching(inlc Q,E-F) 	uding:0-D,8-B,0-	
	Normal character blur matching	Allo	owed length for misidentification (*) 1 2 (©) 3
	Ignore chinese character		

Fig. 14: Whitelist Configuration Settings

- Whitelist enable conditions: To set the working condition for car plate whitelist
- Whitelist pattern match: Car plate pattern match can be set according to actual use case.
- Please note, if SNP131 is using ME-ACS, all number plates will be uploaded to the whitelist using ME-ACS features. Similarly, if you want to delete a plate number from the whitelist, it may require the ME-ACS software

Peripherals

1. In the peripheral settings, you may set the output configuration as below:

Recognition	Output config Serial confi	g Open barrier gate via GPIO	Special license	Supplement light of	onfig F	Peripheral detectio	n
AV settings	Anti-fake car plate						
Basic network	Anti-fake car plate	By click this option, will	verify whitelist car plate	es, fake car plate w	rill not outpu	t linkage control	
White list							
dvanced network	Trigger input	Whitelist verification		Output port			
Peripherals			Switch output 1	Switch output 2	RS485-1	Audio	
Sync		Pass				Default	
Screen voice		No pass				Default	3
ateway configured	Car plate recognition trigg	er No plate car				Default	
		Blacklist				Default	
		Special license				默认	
	Switch/electrical input 1	Without				Default	8
	Switch/electrical input 2	Without				Default	
	Switch/electrical input 3	Without				Default	2
	Switch/electrical input 4	Without				Default	-

Fig. 15: Output Configuration





- Anti fake license plate: When the opening function is enabled, the fake license plate will not trigger the output linkage control.
- When the license plate recognition is triggered, the user can configure the system to output signals at various ports according to the white list verification.
- Users can configure the system to trigger multiple (only partial output ports) output port signals when obtaining input port signals.
- 2. In the GPIO configuration tab, you may set the barrier gate settings as below:

Output config Serial config	Open barrier gate via GPIO	Special license	Supplement light config	Peripheral detection
GPIO barrier gate open time	500	MS		
Secondary open barrier gate	Enable			
Barrier gate opening interval	1000	MS		
Extend output time	0	MS		
Coil loop input port	Switch/electrical input 1	Switch/ele	ectrical input 2	
	Switch/electrical input 3	Switch/ele	ectrical input 4	
Coil loop output port	Switch output 1	Switch out	tput 2	
Wait opening	Enable			
Wait input port	Switch/electrical input 1	Switch/ele	ectrical input 2	
	Switch/electrical input 3	Switch/ele	ectrical input 4	
Wait timeout	0	MS		
Delayed opening time	2000	MS		
			Confirm	

Fig. 16: GPIO Opening Configuration

- Barrier Gate Opening Time: By default, the opening time of GPIO is set
- **Enable the secondary opening**: After enabling, the vehicle unrecognized by the camera can be triggered to open the barrier gate through the ground induction coil.
- **Gate interval time**: To set the minimum interval time of opening the gate twice. Only when the front car passes and the gate falls, the gate can be opened for the rear car after the interval time.
- **Extend the output time**: To set the extension time of the ground induction coil to the output signal after the vehicle induction disappears.
- **Ground induction input port**: The port for receiving the ground induction coil signal.
- **Ground induction output port**: The port for outputting signal of the ground induction coil.

© 2025 QG V2.1 SNP131 MAG LPR



3. In the LED configuration tab, you may configure the LED fill light settings as below:

Output config	Serial config	Open barrier gate via GPIO S		Special license	Supplement light config	Peripheral detection
LED		Manual LED		•		
		Supplement period	Start time	End time	Supplement distance	
		Time frame 1	00 : 00 🗢	09 : 00 🗢	4m 👻	
		Time frame 2	09 : 00 🌻	18 : 00 🌻	Close 👻	
		Time frame 3	18 : 00 🌻	00 : 00 \$	4m -	
					Confirm	

Fig. 17: LED Fill Light Configuration

- Fill light mode: Select the working state of fill light.
- You can set the LED fill light configuration in different time periods by adjusting the time periods and LED installation distance (refer to page 10 on LED installation)

4. After setting up all IO connections, you may use the peripheral detection tab to check the connection status of the ports as shown below:

Output config Serial	config Open b	onfig Open barrier gate via GPIO		Supplement light config	Peripheral detection		
ю	Status	Operation					
Switch/electrical input 1	1	Get					
Switch/electrical input 2	1	Get					
Switch/electrical input 3	1	Get					
Switch/electrical input 4	1	Get					
Switch output 1	0	0	•				
Switch output 2	0	0	*				

Fig. 18: Peripheral Detection

- In the input port section, click the get button to get the current port connectivity status.
- In the output port section, select the path/open option to set the current port status to on/off.

© 2025 QG V2.1 SNP131 MAG LPR



-		 	
1			-
-	<u> </u>		

LED Screen Display Setting

Recognition	Screen dis	play agreement	/oice broadcast				
AV settings							
Basic network	Screen dis	play agreement A		* 💿 Simple config 💿 Common config 💿 Fully config	Jump to serial port o	config	
White list	Choice	Field name	Format	Explain	General configura	tion	
vanced network		Car plate exist / not	1 Byte	0xAA:recognizd , 0xBB:unrecognized	Mark tail	DDoo	
Peripherals		Color	1 Byte	00:blue 01.vellow 02:black 03.white 04:spared	Check start bit	Car plate e	xist / .
Sync		0000	10,0	Chinese character is refered to energification document permat	Check end bit	Direction	
creen voice		Plate	7 Byte	characters are ASCII	Parity bit	Xor	
way configured		Reliability	1 Byte	Reliability full score 100	Little big endian	Little endia	n
	178	Whitelist verification	1.044	04 va off a d 02 var elaks 04 bis added alkey alkedian	Plate encryption	No encrypt	ion
		results	1 Dyte	01.Vermed 03.no plate 04.blackinst other situation	Chinese character	UTF-8	
		Direction	1 Byte	0:NG 1:left 2:right 3:up 4:down	encoding		
		License	1 Byte	0:unknown car plate 1:blue car plate viehcle 2:black car plate viehcle refer to specification	Plate model	Normai mo	de
	[!"]	Car plate area	8 Byte	Include Upper left corner coordinate, length and width, 4 2-bytes	Voice config	Broadcast	t
	1000	Transaction of the second	104	inneger	Status	Whitelist vi	alid
	-	Ingger	1 Byte	1.auto,2.external,4.software,8.virtual coll loop	viaid 7 tible car plate viehcle 2:black car plate Friate model r specification Voice config Enable voice aft corner coordinate, length and width, 4 2-bytes Enable voice Status aft software, 8 virtual coll loop Voice head Voice head w 02-black 10 swhite fld softwares Voice head Voice head		
		Car color	1 Byte	00:blue 01;yellow 02:black 03;white 04:others	Voice tail		
		Time	4 byte(timestamp)+	Recognition time	Up	Down	Con
	0110	Whitelist expire time	4 byte(timestamp)+	Whitelist expire time			100000
		Output IO	1 Byte	00:OUT1 01:OUT2 02:OUT3 03:OUT4			
		SN	8 Byte	X000-X00X			
	023	Ciphertext	16 Byte	Intercept first 16 bytes of ciphertext , insufficient bytes add 0			
	073	Recognition id	4 Byte	Recognition record			
	Example	BB88AA000041313	2333435630000FF				

1. In the screen voice tab, you may configure the LED screen display as below:

Fig. 19: LED Screen Display Configuration

- According to the screen display agreement, select the corresponding LED screen model. For SNP131-DSP , select model = L(ML_IV)
- **Quick configuration**: You can quickly configure the screen output by selecting the corresponding fields to display.
- **Output format**: You can view the field output examples at the bottom of the table.
- **General configuration**: Used for integrity verification and encryption of output field information.
- Voice configuration: Used to enable/disable voice or license plate broadcasting.
- Adjust field display position: Select the field and click the move up / move down button to adjust the field position.
- Click the confirm button to save the configuration.



Wiring Connection

WIRING DIAGRAM SNP131



Important Notes:

- IP address SNP131 must in the same network as ME-ACS

- LED Display SNP131-DSP, must connected to A1 B1 accordingly and the model L(ML_IV) is choose to make sure the number plate capture is display correctly on LED Display.Refer Page 15

- For SNP131 to control barrier gate, the connection OUT1 must connected to UP terminal on the Barrier Gate. OUT2 is additional output from NVR, please refer page 12.

- SNP131 can have external trigger to capture number plate and this is optional connection. This is commonly used for Loop Coil Detector.

- Surge protector is important to make sure device is protected from surge

*Product performances is based on testing in a controlled environment. Your result may vary due to several external and environment factors.

© COPYRIGHT 2025. This documentation served as a reference only. It is subject to change without further notice. All the diagrams and information in this documentation may not be duplicated or modified in any form without the written approval from the management.



© 2025 QG V2.1 SNP131 MAG LPR