

**QUICK GUIDE**



**SNP141**  
**MAG License Plate  
Recognition**



## Device Interface Description



No.	Function	Label	Description
1	Power	DC 12V; GND	Standard 12Vdc (3A to 5A)
2	Light indicator	SYS (Green)	Flashing means the system is currently working properly, whereas continuous on or off means starting or abnormal.
3	SD Card Slot	TF-CARD	SD card slot, maximum 256GB
4	Network Interface (RJ45 LAN1)	RJ45/LAN 1	Supports 10/100Mbps Ethernet transmission
5	Network Interface (RJ45 LAN2)	RJ45/LAN 2	Support 10/100/1000Mbps Ethernet transmission.
6	Serial Port (RS485-1)	A1/B1	Connect to LED Display.
7	Serial Port (RS485-2)	A2/B2	Spare
8	Output terminal (Alarm Out)	OUT1/OUT2/ OUT3/OUT4	Can be used for barrier gate opening.
9	Input terminal (Alarm In)	IN1/2/3/4 /GND	Can be connected to grounded sensing coils for external signal triggering and capturing images.
10	Reset	RESET	Press for 5 to 10 seconds for a long time, and the equipment will fully restore to factory configuration.

## Equipment Installation

### LPR Camera Installation




Fig. 1: Installation Diagram of LPR Camera

#### Installation Requirements

1. Install in front of the barrier gate.
2. About **3 - 6m** from the virtual coil (**L1**).
3. About **3 - 4m** from the loop detector (**L2**).
4. The **pitching angle of camera & fill light** is installed is recommended to be between **15°-40°** and as far as possible.

## LED Fill Light Installation




Fig. 2: Installation diagram of LED Fill Light

### Installation Requirements:

- Distance, D: The recommended distance between the fill light and license plate is around 4m.
- Angle, C: The fill light should be angled so that it illuminates the license plate in the recognition area (around 15° - 45°) and avoids overexposure.
- Vertical Height, H: The fill light should be kept at a vertical distance of 0.5m – 0.7m away from the LPR camera.

## Typical Installation Scenario of LPR Camera



Ensure that car plate is kept close to horizontal line



Too large angle with horizontal line might lead to accuracy issues

## Setting Up SNP141

1. The factory default IP configuration for SNP141 is **192.168.1.100** (username: **admin**, Password: **admin**)
2. Before connecting to the camera, confirm whether the IP address of the current computer and the camera IP address are in the same network segment.
3. After powering up the LPR camera, open browser and input the IP address [http://192.168.1.100 /](http://192.168.1.100/)



Fig. 3: Login Page

4. For first time setup using Internet Explorer browser, kindly install the plugin when the prompt pops up (not necessary for other browser types)



Fig. 4: Install plugin prompt (IE browser only)

5. Enter the default user name "admin", the default password "admin", and click the login button to log in.

6. After logging in, the main interface is as shown below:




Fig. 5: Web Portal Main Page

7. In the real-time video display, the recognition area and virtual coil loop is marked by default.
8. Double-click on OSD to enter full screen mode and double-click again to exit.
9. To create area, select the navigation button below OSD to create area according to type of area is needed.
10. To edit the area, click somewhere within the area (the border line of area will turns to blue from red, once successfully be selected.) To remove the area, select the area and remove it via the bottom navigation button provided.
11. To adjust the shape of the area, use the red points on the vertex to adjust the shape and size of the area. Multiple red points can be added and adjusted, once the point was created successfully.
12. Shielded area can be used to cover up the area needed to be ignored to avoid unwanted recognition like car park area and others irrelevant vehicle lane.




Fig. 6: Default Area Configuration of Recognition Area & Virtual Coil Loop

13. After completing the adjustment, click on “Save rules” to save the configuration for both recognition area and virtual coil loop area.

**Important Note:**

**Recognition/Identification Area:** When the vehicle enters the identification area, it will start to identify and analyse the license plate.

**Virtual Coil Loop:** When the vehicle enters the virtual coil loop area (trigger area), the recognition result of the license plate will be sent.

For **6MM Prime Lens**, functions with zoom & auto-focus cannot be used since it was a fixed camera lens.

Positioning of Virtual Coil Loop

1. When calibrating the recognition area and virtual coil loop area, you may separate the video screen into 3 segments. The Virtual Coil Loop should be positioned at the lower 3rd segment of the video height.




Fig. 7: Positioning of Virtual Coil Loop

2. Ensure that the left and right area of the Virtual Coil Loop is able to cover the car license plate.

### Recognition Area Full Coverage

1. When calibrating the recognition area, make sure to include the effective range of movement of the license plate on the screen.



Fig. 8: Recognition Area Adjustment according to Site

2. When calibrating the recognition area, ensure more area is included for the vehicle to gain more video streams and more recognition frames for better accuracy.

### Event Capture

1. After completing the LPR calibrations, incoming vehicle car plates will be captured automatically and the identified license plate number will be displayed on the right side.




Fig. 9: Car Plate Identification Result

2. To manually trigger the car plate recognition, click on the “Trigger” button to manually capture a test image. The captured image will automatically display the close-up car image and the license plate, whereas the license plate number identified will be displayed on the right side.
3. Under the real-time display interface, there is a snapshot event history of all the car plates identified.

Time	Plate	Width	White list	Trigger	Trigger coil	Event type
2025-08-22 17:39:11	BQB8413	523Pixel	Temporary vehicle	Virtual coil loop	Virtual coil loop	Virtual coil loop
2025-08-22 17:39:12	BQB843	419Pixel	Temporary vehicle	Virtual coil loop	Virtual coil loop	Virtual coil loop
2025-08-22 17:39:15	BQB8413	490Pixel	Temporary vehicle	Virtual coil loop	Virtual coil loop	Virtual coil loop
2025-08-22 17:39:21	BQB8413	391Pixel	Temporary vehicle	Virtual coil loop	Virtual coil loop	Virtual coil loop

Fig. 10: Identified Car Plate Event Log

## Device Settings

At the top of the interface, click on Options to enter the advanced setting menu as shown below:




Fig. 11: Advance Setting Interface


## Recognition/ Identification Setting

1. Use the Trigger Mode to switch between different types of identification trigger.
2. Recognition parameters can be used to change image resolution, image quality, result delay, car plate pixel limit and same plate trigger intervals.

Fig. 12: Identification Setting Interface

## Basic Network Settings

In the basic setting tab, you may configure the basic network settings as follows:



Basic setting		DDNS	UPNP	Network diagnosis	Device discovery	MTU
Recognition						
AV settings						
<b>Basic network</b>	<b>Basic setting</b>					
White list						
Advanced network						
Peripherals						
Screen voice						
Parking lot						

**LAN1**

IP	192.168.1.100
Netmask	255.255.255.0
Gateway	192.168.1.1
DNS server	114.114.114.114
DNS server 2	8.8.8.8

**LAN2**

IP	10.10.1.100
Netmask	255.255.128.0
Gateway	10.10.1.1

**Port configuration**

HTTP port	80
RTSP port	8557
WebSocket port	9080

**Confirm**

Fig. 13: Basic Network Settings

- **IP:** To configure the network IP address.
- **Netmask:** To configure the subnet mask of the network.
- **Gateway:** To configure the network default gateway. It should be in the same network segment as the IP address
- **DNS server:** To configure the DNS server of the network. After configuring the network parameters, click OK to take effect.
- **DNS server 2:** To configure the standby DNS server, and automatically switch to this DNS server when there is connection error in the default DNS server
- **HTTP port:** To configure the port number of HTTP protocol. The default is 80. Click confirm button to take effect.
- **RTSP port:** To configure the port number of RTSP video stream. The default is 8557. Click confirm button to take effect.
- **WebSocket port:** To configure full duplex real time communication, 9080 as default. Click confirm button to take effect.

## White List

In the white list configuration tab, you may configure white list as follows:




Fig. 14: Whitelist Configuration Settings


- Whitelist enable conditions: To enable the working condition for car plate whitelist
- Whitelist pattern match: Accuracy of car plate pattern match can be set according to actual use case.

### Important Note:

If SNP141 is using ME-ACS, all number plates will be uploaded to the whitelist using ME-ACS features. Similarly, if you want to delete a plate number from the whitelist, it may require the ME-ACS software.

## Peripherals

1. In the peripheral settings, you may set the output configuration as below:




Trigger input	Whitelist verification	Output port
Car plate recognition trigger	Pass	<input checked="" type="checkbox"/> Switch output 1 <input type="checkbox"/> Switch output 2 <input type="checkbox"/> Switch output 3 <input type="checkbox"/> Switch output 4 <input type="checkbox"/> RS485-1 <input type="checkbox"/> RS485-2 <input type="checkbox"/> Audio
	No pass	<input type="checkbox"/> Default
	No plate car	<input type="checkbox"/> Default
	Blacklist	<input type="checkbox"/> Default
Switch/electrical input 1	<input type="checkbox"/> Default	
Switch/electrical input 2	<input type="checkbox"/> Default	
Switch/electrical input 3	<input type="checkbox"/> Default	
Switch/electrical input 4	<input type="checkbox"/> Default	

Fig. 15: Output Configuration

- Anti-fake car plate: When the opening function is enabled, the fake license plate will not trigger the output linkage control.
- When the license plate recognition is triggered, the user can configure the system to output signals at various ports according to the white list verification.
- Users can configure the system to trigger multiple (only partial output ports) output port signals when obtaining input port signals.

2. In the GPIO configuration tab, you may set the barrier gate settings as below:



Setting	Value
GPIO barrier gate open time	500 MS
Secondary open barrier gate	<input type="checkbox"/> Enable
Barrier gate opening interval	1000 MS
Extend output time	0 MS
Coil loop input port	<input checked="" type="radio"/> Switch/electrical input 1 <input type="radio"/> Switch/electrical input 2 <input type="radio"/> Switch/electrical input 3 <input type="radio"/> Switch/electrical input 4
Coil loop output port	<input checked="" type="radio"/> Switch output 1 <input type="radio"/> Switch output 2 <input type="radio"/> Switch output 3 <input type="radio"/> Switch output 4

Fig. 16: GPIO Opening Configuration



- **Barrier Gate Opening Time:** By default, the opening time of GPIO is set.
- **Enable the secondary opening:** After enabling, the vehicle unrecognized by the camera can be triggered to open the barrier gate through the ground induction coil.
- **Gate interval time:** To set the minimum interval time of opening the gate twice. Only when the front car passes and the gate falls, the gate can be opened for the rear car after the interval time.
- **Extend the output time:** To set the extension time of the ground induction coil to the output signal after the vehicle induction disappears.
- **Ground induction input port:** The port for receiving the ground induction coil signal.
- **Ground induction output port:** The port for outputting signal of the ground induction coil.

3. In the LED configuration tab, you may configure the LED fill light settings as below:




Fig. 17: LED Fill Light Configuration

- **Fill light mode:** Select the working state of fill light.
- For manual LED mode, You can set the LED fill light configuration in different time periods by adjusting the time periods and LED installation distance.

4. After setting up all IO connections, you may use the peripheral detection tab to check the connection status of the ports as shown below:

Output config	Serial config	Open barrier gate via GPIO	Supplement light config	Peripheral detection
<b>IO</b>				
Switch/electrical input 1	1		Get	
Switch/electrical input 2	1		Get	
Switch/electrical input 3	1		Get	
Switch/electrical input 4	1		Get	
Switch output 1	0	0	0	
Switch output 2	0	0	0	
Switch output 3	0	0	0	
Switch output 4	0	0	0	

Fig. 18: Peripheral Detection

- In the input port section, click the get button to get the current port connectivity status.
- In the output port section, select the path/open option to set the current port status to turn on/off.

## LED Screen Display Setting

In the screen voice tab, you may configure the LED screen display as below:




Fig. 19: LED Screen Display Configuration

- According to the screen display agreement, select model = L(ML\_IV) for SNP141-DSP MAG Two lines LED Display.
- For serial port connection, select 1 for RS485-1 (Port 1) while 2 for RS485-2 (Port 2).
- Screen display can be set with both idle and busy condition, content of idle can be selected along with time, while car license plate can be showed along with content under busy condition.
- Select a time for traffic light delay for every first time screen display agreement configuration.
- Click the confirm button to save the configuration.

## Wiring Connection




Fig. 20: Wiring Diagram

## Important Notes:

- IP address of the SNP141 has to be same network as ME-ACS software.
- LED Display SNP141-DSP, (A1 & B1) have to be fully connected accordingly and the agreement of L(ML\_IV) is choose to ensure that is the same captured license plate from camera to be displayed on LED display as expected.
- For SNP141 to control barrier gate, output terminal connection likes Alarm Out (OUT1) have to be connected to UP terminal of the Barrier Gate.
- SNP141 can have external trigger to capture license plate and this is optional connection. This is commonly used for Loop Coil Detector.
- Surge protector is essential to protect electronic equipment from damaging power surges by diverting excessive voltage from a lightning strike or other electrical anomaly to the ground.

**\*Product performances is based on testing in a controlled environment. Your result may vary due to several external and environment factors.**

© COPYRIGHT 2025. This documentation served as a reference only. It is subject to change without further notice. All the diagrams and information in this documentation may not be duplicated or modified in any form without the written approval from the management.

